

## USER'S MANUAL 1/2

### (Specification and Part Names)

WIDE PLASMA DISPLAY P42VHA40W/P42HHA40W/P50XHA40W/P55XHA40W P42VHA40U/P42HHA40U/P50XHA40U/P55XHA40U P42VHA40R



# **Plasmavision**™



### Contents

	Page
Before Use	
CHECKING ACCESSORIES	E-2
• INSTALLATION	E-3
Usage	
PART NAMES AND FUNCTIONS	E-4
Others	
• OPTIONS	E-9
MAIN SUPPORTED SIGNALS	E-10
SPECIFICATION	F-12

Before using the display, read the User's manual (1/2) and the User's manual (2/2) carefully so that you know how to use the display correctly.

Refer to this manual whenever questions or problems about operation arise. Be sure to read and observe the safety precautions (see the separate "Safety Precautions" manual).

Keep this manual where the user can see it easily.

- \* Installation and removal require special expertise. Consult your product dealer for details.
- \* When "English" is selected at "Language" of the on-screen display, "colour" will be displayed in the case of the R model and "color" will be displayed for all other models.

The notation used in this users' manual is "color".

## **CHECKING ACCESSORIES**

### **Display Section**

One power cable



(for the W/R models)



(for the U model)

Two small ferrite cores



Two big ferrite cores



Three user's manuals



One remote control (for the W/R models)



One remote control (for the U model)



Two AA batteries



### **CONNECTING THE DISPLAY TO EXTERNAL EQUIPMENT**

Carefully check the terminals for position and type before making any connections.


Loose connectors can result in picture or color problems. Make sure that all connectors are securely inserted into their terminals.


### Ferrite cores

These ferrite cores are used to attenuate undesired signals.

### Two big ferrite cores


When connecting a cable to the power input terminal, video input terminal (VIDEO1 INPUT), attach one of these ferrite cores to the cable near the terminal.






### Two small ferrite cores

When connecting a cable to the external speaker output terminal attach one of these ferrite cores to the cable near the terminal.





## **INSTALLATION**

To prevent the display's internal components from overheating, make sure that the display is installed in a well-ventilated location.

Be sure to use the optional stand, wall-mounting unit or the other unit when installing the display. Also, be also sure that your dealer performs the installation.


See the appropriate instruction manual for more information on the installation hardware you select.

To prevent an accident and ensure safety in the event of an earthquake, fix the display securely into position as described below.

To ensure proper heat radiation, provide at least as much space around the display as shown below.

- \* Make sure that the display is installed in a location where the temperature can be maintained between 0°C and 40°C.
- \* Never attempt to tilt the display sideways or backward.
- \* To prevent the power and other cables from being accidentally pulled, make sure that they run along the wall or through corners.
- \* To prevent accidents and ensure safety in the event of an earthquake, secure the display to prevent it from tipping over.

#### **Display Section**



### Note


The display is a highly precise piece of equipment and therefore must be packed properly before transportation. Be sure to use only those packing materials originally supplied with the display when repacking it.

#### Reference

See P. E-9 for more information on options.

## PART NAMES AND FUNCTIONS

### **DISPLAY SECTION - FRONT**



#### Power indicator lamp

This lamp shows the state of the power supply.

Lit (red): Stand-by state
Lit (green): Power ON state

Flashing (red or green): Malfunction (Flashes differently

depending on the type of

malfunction.)

### ② Remote control signal receiver

Receives signals from the remote control.

- ③ Input mode selector button ▲ [MODE]
- ④ Input mode selector button ▼ [MODE]

Switches between picture input modes.

- ⑤ VOL + button
- 6 VOL button

Adjusts the audio volume.

### 7 Wide screen selector button [WIDE]

Switches the screen over to a desired wide screen.

### ON/OFF button

Turns the power "ON" and "OFF (standby state)".

### Ambient Sensor


Detects the brightness of external light.

Do not obstruct it.

#### Warning

If the power indicator lamp flashes red or green, this signifies that the display has developed a problem. When this happens, be sure to remove the power plug from the receptacle and contact your dealer. Leaving the display power ON can result in fire or electric shock.

## **DISPLAY SECTION – BACK AND BOTTOM PART**



### ① **b**/I power switch

If this button is pressed when the power indicator lamp is off, the indicator lamp will light.

The power can be turned on and the standby mode selected by using the remote control or the control panel of the display.

If this button is pressed when the power indicator lamp is lit, the indicator lamp will go out.

\*Power is still supplied to parts of the display even if the indicator lamp is off.

### ② HDMI input terminal (VIDEO5 INPUT/HDMI) for the U model

Connect this terminal to the HDMI output terminal for DVD, etc.

### ③ RS-232C terminal (RS-232C)

This terminal is provided for you to control the display from the PC. Connect it to the RS-232C terminal on the PC.

### 4 RGB1 input terminal (RGB1 INPUT/DVI-D) for the W/U models

Connect this terminal to the PC's display (digital RGB) output terminal.

\*The connection cable No.88741-8000 made by molex Inc. is recommanded.

## **PART NAMES AND FUNCTIONS (Continued)**

## (5) RGB2 input terminal (RGB2 INPUT/mD-sub) for the W/U models / RGB1 input terminal (RGB1 INPUT/mD-sub) for the R model

Connect this terminal to the PC's display (analog RGB) output terminal or decoder (digital broadcast tuner, etc.) output terminal.

- (6) Component video input terminal (VIDEO3 INPUT)
- ⑦ Component video input terminal (VIDEO4 INPUT)

Connect this terminal to the component video output (color difference output) terminal of your HDTV unit or DVD player.

**® Video input terminal (VIDEO1 INPUT)** 

Connect this terminal to the video output terminal of your VCR. When connecting a cable, attach a ferrite core to the cable. (See P. E-2.)

S-Video input terminal (VIDEO2 INPUT)

Connect this terminal to the S-video output terminal of your VCR.

- Audio3 input terminal (AUDIO3 INPUT)
- (1) Audio2 input terminal (AUDIO2 INPUT)
- Audio1 input terminal (AUDIO1 INPUT)

Connect this terminal to the audio output terminal of your VCR, etc. (See the User's manual (2/2) for the selection of audio input for video input.)

(3) External speaker output terminal (EXT SP)

Connect this terminal to the optionally available speaker. When connecting a cable, attach a ferrite core to the cable. (See P. E-2.)

\* See the speaker instruction manual for more information.

#### Power input terminal

Connect this terminal to the power cable supplied with the display. When connecting a cable, attach a ferrite core to the cable. (See P. E-2.)


## **DESCRIPTION OF INPUT TERMINALS**

DVI-D terminal (RGB1 INPUT/DVI-D) for the W/U models




Pin No.	Signal	Pin No.	Signal	Pin No.	Signal
1	T.M.D.S. Data2-	9	T.M.D.S. Data1-	17	T.M.D.S. Data0-
2	T.M.D.S. Data2+	10	T.M.D.S. Data1+	18	T.M.D.S. Data0+
3	T.M.D.S. Data2 Shield	11	T.M.D.S. Data1 Shield	19	T.M.D.S. Data0 Shield
4	_	12	_	20	_
5	_	13	_	21	_
6	DDC Clock	14	+5V Power	22	T.M.D.S. Clock Shield
7	DDC Data	15	Ground (for +5V)	23	T.M.D.S. Clock+
8	_	16	Hot Ploug Detect	24	T.M.D.S. Clock-

mD-sub input terminal (RGB2 INPUT/mD-sub) for the W/U models (RGB1 INPUT/mD-sub) for the R model



Pin No.	Input signal	Pin No.	Input signal
1	Red	9	_
2	Green	10	Ground
3	Blue	11	_
4	_	12	_
5	Ground	13	Horizontal synchronization
6	Ground	14	Vertical synchronization
7	Ground	15	_
8	Ground	Frame	Ground

RS-232C terminal (RS-232C)



Pin No.	Signal
1	DCD (Data Carrier Detect)
2	RD (Received Data)
3	TD (Transmit Data)
4	DTR (Data Terminal ready)
5	GND (Ground)
6	DSR (Data Set Ready)
7	RTS (Request To send)
8	CTS (Clear To Send)
9	RI (Ring Indication)

# **PART NAMES AND FUNCTIONS (Continued)**

HDMI input terminal (VIDEO5 INPUT/HDMI) for the U model



Pin No.	Input signal	Pin No.	Input signal
1	T.M.D.S. Data2+	11	T.M.D.S. Clock Shield
2	T.M.D.S. Data2 Shield	12	T.M.D.S. Clock-
3	T.M.D.S. Data2-	13	CEC
4	T.M.D.S. Data1+	14	Reserve
5	T.M.D.S. Data1 Shield	15	DDC Clock
6	T.M.D.S. Data1-	16	DDC Data
7	T.M.D.S. Data0+	17	Ground (for +5V)
8	T.M.D.S. Data0 Shield	18	+5V Power
9	T.M.D.S. Data0-	19	Hot Plug Detect
10	T.M.D.S. Clock+	Frame	FG



### **HDMI (High-Definition Multimedia Interface)**

HDMI is a standard for home digital interfaces, which can transmit images as well as multichannel audio signals and control signals through one cable.

## **OPTIONS**

Wall-mounting Bracket	0° to 15° mounting angle	P-WB4201 (for 42" model/50" model)	-
		P-WB6300 (for 55" model)	
Ceiling unit	0° to 15° mounting angle	P-CT4200 (for 42" model/50" model)	
		P-CT6300 (for 55" model)	
Desktop Stand unit		P-TT4202 (for 42" model/50" model/55" model)	
Speaker (1 set of 2 speakers)		P-SP1000 (for attaching to the display) for 42" model/50" model	
		P-SP5010 (for attaching to the display) for 55" model	
		P-SP4200 (for mounting on the speaker stands) for 42" model	
		P-SP5010 (for mounting on the speaker stands) for 50" model/55" model	
Desktop Speaker Stand		P-ST4200 (for P-SP4200)	
(1 set of 2 speaker stands)		P-ST5000 (for P-SP5010)	0 0

- \* When installing an option, make sure that all installation requirements for that option (as given in the relevant instruction manual) are met.
- \* The colors of options do not match the display colors perfectly.
- \* To improve the function and performance of optional accessories, specifications and part names may change. Consult your local dealer before purchasing.

### Warning

To prevent injury, fire, and electric shock, arrange for options to be initially installed (or installed at a different location) by your dealer.

#### **CAUTION**

This display (P42VHA40/P42HHA40/P50XHA40) is for use only with Fujitsu General Limited's option (P-WB4201, P-CT4200, P-TT4202). This display (P55XHA40) is for use only with Fujitsu General Limited's option (P-WB6300, P-CT6300, P-TT4202). Using this display with other option can cause instability resulting in possible injury.

## MAIN SUPPORTED SIGNALS

This display can store the latest four types of signals for RGB adjustment value. The fifth input signal will replace the adjustment value of the first input signal.

To do this, select a desired signal and follow the instructions in "Adjusting Screen Position and Size" on the User's manual (2/2) to adjust the parameters.

When you finish, the settings will be automatically stored. Thus, when the display receives that signal, pictures will be displayed in accordance with the settings you most recently selected.

### Main corresponding signals (RGB mode)

Display (dots x lines)	Horizontal frequency (kHz)	Vertical frequency (Hz)	Signal	DVI-D
640 x 480	31.47	59.94	VGA	0
640 x 480	37.50	75.00	VGA 75 Hz	
640 x 480	43.27	85.01	VGA 85 Hz	
720 x 400	31.47	70.09	400 lines	0
800 x 600	37.88	60.32	SVGA 60 Hz	0
800 x 600	46.88	75.00	SVGA 75 Hz	
800 x 600	53.67	85.06	SVGA 85 Hz	
1024 x 768	48.36	60.00	XGA 60 Hz	0
1024 x 768	60.02	75.03	XGA 75 Hz	
1024 x 768	68.68	84.99	XGA 85 Hz	
1280 x 1024	63.98	60.02	SXGA 60 Hz	
1280 x 1024	79.98	75.03	SXGA 75 Hz	
848 x 480	31.02	60.00		0
852 x 480	31.72	59.97		
1360 x 768	47.71	60.01		0*
720 x 485	15.73	59.94	60 fields	
720 x 575	15.63	50.00	50 fields	

<sup>\*</sup> With some input signals, "Out of range" may appear even when the horizontal and vertical frequencies are within their permissible ranges. In this event, match the input signals to another frequency rather than those listed above.

\*It doesn't support the model with 42" display (displayed pixels 852 x 480 dots x lines).

<sup>\*</sup> In the DVI-D mode, the input signal can be restricted partly.

In the Comp.video and Video/S-video, the display has been factory-set as follows for different input signals:

### Main corresponding signals (Comp.video mode)

### Main corresponding signals (Video, S-video mode)

Horizontal frequency (kHz)	Vertical frequency (Hz)	Signal	HDMI
15.73	59.94	SDTV 480i	0
15.63	50.00	SDTV 576i	0
31.47	59.94	SDTV 480p	0
31.25	50.00	SDTV 576p	0
45.00	60.00	HDTV 720p	0
37.50	50.00	HDTV 720p	0
33.75	60.00	HDTV 1080i	0
28.13	50.00	HDTV 1080i	0

Horizontal frequency (kHz)	Vertical frequency (Hz)	Signal
15.73	59.94	NTSC
15.63	50.00	PAL
15.63	50.00	SECAM
15.63	59.52	PAL60
15.63	50.00	N-PAL
15.73	59.95	M-PAL
15.73	59.94	4.43NTSC

- Depending on the input signal, the display may show pictures of reduced size due to size reduction and interpolation.
- "Out of range" appears if the display receives a signal whose characteristic does not fall within the display's permissible range.
- You can check input signals through "Information" on the FEATURES Menu screen. (See User's Manual (2/2))
- · In order to facilitate the explanations, pictures and diagrams in this manual may differ slightly from the actual items.
- All terms (i.e., company and product names) used in this document are trademarks or registered trademarks.

## **SPECIFICATION**

### **WIDE PLASMA DISPLAY**

Model	P42VHA40W	P42HHA40W	P50XHA40W	P55XHA40W
Screen size	42" wide screen: 92.1 cm (W) x 51.8 cm (H) (105.7 cm diagonal) 36.3 inch (W) x 20.4 inch (H) (41.6 inch diagonal)	42" wide screen: 92.2 cm (W) x 52.2 cm (H) (106.0 cm diagonal) 36.3 inch (W) x 20.6 inch (H) (41.7 inch diagonal)	50" wide screen: 110.6 cm (W) x 62.2 cm (H) (126.9 cm diagonal) 43.5 inch (W) x 24.5 inch (H) (50 inch diagonal)	55" wide screen: 122.9 cm (W) x 69.1 cm (H) (140.0 cm diagonal) 48.4 inch (W) x 27.2 inch (H) (55.1 inch diagonal)
Aspect ratio	16:9 (wide)			
Number of pixels	852 (H) x 480 (V)	1024 (H) x 1024 (V)	1366 (H) x 768 (V)	
Weight	31.5 kg / 69 lbs		45 kg / 99 lbs	55 kg / 121 lbs
Outer dimensions	103.9 (W) x 64.0 (H) x 8.7 (D) cm 40.9 (W) x 25.2 (H) x 3.4 (D) inch (does not include outer projections)		121.6 (W) x 72.6 (H) x 10.0 (D) cm 47.9 (W) x 28.6 (H) x 3.9 (D) inch (does not include outer projections)	138.0 (W) x 80.8 (H) x 12.5 (D) cm 54.3 (W) x 31.8 (H) x 4.9 (D) inch (does not include outer projections)
Power supply	110-240 VAC 50/60 Hz			
Current rating	3.2-1.35 A	4.2-1.8 A	4.4-1.9 A	5.8-2.3 A
External equipment terminals				
Video input terminals	VIDEO1 INPUT (Video	input)	RCA terminal 1 V	Vp-p/75 Ω
	VIDEO2 INPUT (S-vid	eo input)	S terminal Y: C:	
	VIDEO3/VIDEO4 INPI (Component video inpu		3 RCA terminals Y: PB, PR	1 Vp-p/75 Ω /CB: 0.7 Vp-p/75 Ω /CR: 0.7 Vp-p/75 Ω
PC input terminal	RGB2 input	DVI-D terminal (EIA/CE/mD-sub, 3 rows, 15-pin Picture signal: 0.7 Vp-p/7. Synchronization signal:T1	5 Ω	
Audio terminals	2 audio input pin jacks (L/R) (3 lines) 500 mVrms/at least 22 kΩ			
Control terminal	RS-232C connector (D-sub 9-pin)			
External speaker output terminal	Max. output: 10 W + 10 W, 6 Ω			
Operating conditions	Temperature: 0 to 40 °C / 32 to 104 °F Humidity: 20 to 80 %			
Accessories	3 user's manuals, 1 power	r cable, 2 small ferrite cores	s, 2 big ferrite cores, 1 remo	te control, 2 AA batteries

### Regulation

• UL, CSA Safety: UL6500, C-UL

EMC: FCC Part 15 Class B, ICES-003 Class B

• CE Safety: EN60065

EMC: EN55022 1998, Class B EN61000-3-2 1995 1995 EN61000-3-3 EN55024 1998 EN61000-4-2 1995 1996 EN61000-4-3 EN61000-4-4 1995 EN61000-4-5 1995 EN61000-4-6 1996 1993 EN61000-4-8 1994 EN61000-4-11

• AS Safety: IEC60065 EMC: AS/NZS 3548

### **WIDE PLASMA DISPLAY**

Model	P42VHA40U	P42HHA40U	P50XHA40U	P55XHA40U
Screen size	42" wide screen: 92.1 cm (W) x 51.8 cm (H) (105.7 cm diagonal) 36.3 inch (W) x 20.4 inch (H) (41.6 inch diagonal)	42" wide screen: 92.2 cm (W) x 52.2 cm (H) (106.0 cm diagonal) 36.3 inch (W) x 20.6 inch (H) (41.7 inch diagonal)	50" wide screen: 110.6 cm (W) x 62.2 cm (H) (126.9 cm diagonal) 43.5 inch (W) x 24.5 inch (H) (50 inch diagonal)	55" wide screen: 122.9 cm (W) x 69.1 cm (H) (140.0 cm diagonal) 48.4 inch (W) x 27.2 inch (H) (55.1 inch diagonal)
Aspect ratio	16:9 (wide)			
Number of pixels	852 (H) x 480 (V)	1024 (H) x 1024 (V)	1366 (H) x 768 (V)	
Weight	31.5 kg / 69 lbs		45 kg / 99 lbs	55 kg / 121 lbs
Outer dimensions	103.9 (W) x 64.0 (H) x 40.9 (W) x 25.2 (H) x 3 (does not include outer)	.4 (D) inch	121.6 (W) x 72.6 (H) x 10.0 (D) cm 47.9 (W) x 28.6 (H) x 3.9 (D) inch (does not include outer projections)	138.0 (W) x 80.8 (H) x 12.5 (D) cm 54.3 (W) x 31.8 (H) x 4.9 (D) inch (does not include outer projections)
Power supply	110-240 VAC 50/60 Hz			
Current rating	3.2-1.35 A	4.2-1.8 A	4.4-1.9 A	5.8-2.3 A
External equipment terminals				
Video input terminals	VIDEO1 INPUT (Video	input)	RCA terminal 1 V	Vp-p/75 Ω
	VIDEO2 INPUT (S-vid	eo input)	S terminal Y: C:	
	VIDEO3/VIDEO4 INPU (Component video inpu		3 RCA terminals Y: PB/PR/	1 Vp-p/75 Ω /CB: 0.7 Vp-p/75 Ω /CR: 0.7 Vp-p/75 Ω
	VIDEO5 INPUT		HDMI terminal (HD)	MI type A connector)
PC input terminal	RGB1 input DVI-D terminal (EIA/CEA-861B Compliant) RGB2 input mD-sub, 3 rows, 15-pin Picture signal: 0.7 Vp-p/75 Ω Synchronization signal: TTL level			
Audio terminals	2 audio input pin jacks (L/R) (3 lines) 500 mVrms/at least 22 k $\Omega$			
Control terminal	RS-232C connector (D-sub 9-pin)			
External speaker output terminal	Max. output: $10 \text{ W} + 10 \text{ W}$ , $6 \Omega$			
Operating conditions	Temperature: 0 to 40 °C / 32 to 104 °F Humidity: 20 to 80 %			
Accessories	3 user's manuals, 1 power	r cable, 2 small ferrite core	s, 2 big ferrite cores, 1 remo	te control, 2 AA batteries

### Regulation

• UL, CSA Safety: UL6500, C-UL EMC: FCC Part 15 Class B, ICES-003 Class B

• CE Safety: EN60065

EMC: EN55022 1998, Class B EN61000-3-2 1995 EN61000-3-3 1995 1998 EN55024 EN61000-4-2 1995 1996 EN61000-4-3 EN61000-4-4 1995 EN61000-4-5 1995 EN61000-4-6 1996 EN61000-4-8 1993 EN61000-4-11 1994

• AS Safety: IEC60065 EMC: AS/NZS 3548

- Specifications and external appearance may be change for the sake of improvement.
- Viewing the screen constantly for extended periods can strain your eyes. Be sure to stay at a proper distance (at least 1.5 m or 5 feet for 42" / at least  $1.9~\mathrm{m}$  or  $6.2~\mathrm{feet}$  for 50" / at least  $2.1~\mathrm{m}$  or  $6.9~\mathrm{feet}$  for 55") from the screen and to look occasionally away while working.
- Plasmavision" is a worldwide trademark of Fujitsu General Limited and is a registered trademark in Japan, the U.S.A. and other countries or

## **SPECIFICATION (Continued)**

### **WIDE PLASMA DISPLAY**

Model	P42VHA4	40R			
Screen size	42" wide screen: 92.1 cm (W) x 51.8 cm (H) (105.7 cm diagonal) 36.3 inch (W) x 20.4 inch (H) (41.6 inch diagonal)				
Aspect ratio	16:9 (wide)				
Number of pixels	852 (H) x 480 (V)				
Weight	31.5 kg / 69 lbs				
Outer dimensions	103.9 (W) x 64.0 (H) x 8.7 (D) cm 40.9 (W) x 25.2 (H) x 3.4 (D) inch (does not include outer projections)				
Power supply	110-240 VAC 50/60 Hz				
Current rating	3.2-1.35 A				
External equipment terminals					
Video input terminals	VIDEO1 INPUT (Video input)	RCA terminal 1 Vp-p/75 Ω			
	VIDEO2 INPUT (S-video input)	S terminal	Y: C:	1 Vp-p/75 Ω 0.286 Vp-p/75 Ω	
	VIDEO3/VIDEO4 INPUT (Component video input)	3 RCA terminals	P <sub>B</sub> /C <sub>B</sub> :	1 Vp-p/75 Ω 0.7 Vp-p/75 Ω 0.7 Vp-p/75 Ω	
PC input terminal	RGB1 input mD-sub, 3 rows, 15-pin Picture signal: 0.7 Vp-p/75 Ω Synchronization signal: TTL le	evel			
Audio terminals	2 audio input pin jacks (L/R) (3 lines) 500 mVrms/at least 22 kΩ				
Control terminal	RS-232C connector (D-sub 9-pin)				
External speaker output terminal	Max. output: $10 \text{ W} + 10 \text{ W}$ , $6 \Omega$				
Operating conditions	Temperature: 0 to 40 °C / 32 to 104 °F Humidity: 20 to 80 %				
Accessories	3 user's manuals, 1 power cable, 2 small ferrite cores, 2 b	big ferrite cores, 1 re	emote co	ntrol, 2 AA batteries	

### Regulation

• UL, CSA Safety: UL6500, C-UL

EMC: FCC Part 15 Class B, ICES-003 Class B

• CE Safety: EN60065

EMC: EN55022 1998, Class B EN61000-3-2 1995 EN61000-3-3 1995 EN55024 1998 EN61000-4-2 1995 EN61000-4-3 1996 EN61000-4-4 1995 EN61000-4-5 1995 EN61000-4-6 1996 EN61000-4-8 1993 EN61000-4-11

• AS Safety: IEC60065 EMC: AS/NZS 3548

- Specifications and external appearance may be change for the sake of improvement.
- Viewing the screen constantly for extended periods can strain your eyes. Be sure to stay at a proper distance (at least 1.5 m or 5 feet for 42" / at least 1.9 m or 6.2 feet for 50" / at least 2.1 m or 6.9 feet for 55") from the screen and to look occasionally away while working.
- Plasmavision" is a worldwide trademark of Fujitsu General Limited and is a registered trademark in Japan, the U.S.A. and other countries or



# USER'S MANUAL $\frac{2}{2}$

(Precautions and Adjustment Methods)
WIDE PLASMA DISPLAY



# **Plasmavision**™

Cont	ents
Page	Page
Before Use	OTHER ADJUSTMENTSE-29
• INFORMATION E-2	• INITIALIZATION OF USER ADJUSTMENT VALUE E-35
Usage	Others
USING THE REMOTE CONTROLE-3	CLEANING AND MAINTENANCEE-36
<ul> <li>CONNECTING THE DISPLAY TO EXTERNAL</li> </ul>	
EQUIPMENTE-7	
BASIC OPERATIONSE-12	
SELECTING INPUT MODEE-14	
OTHER BASIC OPERATIONSE-16	
WATCHING PICTURES ON THE WIDE SCREENE-17	
Adjustments	
ADJUSTMENT MENUE-19	
BASIC PROCEDURE OF ADJUSTMENT MENU	
OPERATIONSE-20	
ADJUSTING THE PICTUREE-21	
ADJUSTING SCREEN POSITION AND SIZEE-27	
ADJUSTING AUDIOE-28	

Before using the display, read the User's manual (1/2) and the User's manual (2/2) carefully so that you know how to use the display correctly.

Refer to this manual whenever questions or problems about operation arise. Be sure to read and observe the safety precautions (see the separate "Safety Precautions" manual).

Keep this manual where the user can see it easily.

- \* Installation and removal require special expertise. Consult your product dealer for details.
- \* When "English" is selected at "Language" of the on-screen display, "colour" will be displayed in the case of the R model and "color" will be displayed for all other models.

The notation used in this users' manual is "color".

## **INFORMATION**

· Receptacle

Make sure that the power cable's grounding wire is grounded.

The display comes with a 3-prong power plug; one prong is connected to the grounding wire. If you have only a 2-hole receptacle, you will need to have it replaced. Contact your dealer for more information.

- Have the display inspected and cleaned by your dealer at regular intervals.
- Pictures may become "burnt" into the screen phosphors if the screen is left on for extended periods. To ensure that the display has a prolonged service life, be sure to use a screen orbiter, white screen. This will ensure the same picture or pattern is not constantly displayed for long periods. (See P. E-33.)
- Extremely high-precision technology has been used in the manufacture of the plasma display panel, with the effective pixel elements exceeding 99.99%. Please be aware, however, that fewer than 0.01% of the pixels may be missing or remain constantly lit.
- Some models are fitted with a radiator fan to prevent the display's internal temperature from rising during operation. Be careful of the air emitted by the radiator fan, as it may be hot.
- Contact your dealer if you find that the display does not seem to function properly when used with other audio-visual equipment.

  You may need to move your display if it produces degraded pictures or noise due to electromagnetic radiation, or if the infrared remote control does not function properly.
- Pictures may not be displayed properly if you connect a non-standard PC to the RGB input terminal. In this case, contact your dealer for more information.
- The protective circuit, built into the display, automatically turns off the power if the display has a problem. In this case, you will see that the power indicator lamp flashes red or green.

#### Warning

If the power indicator lamp flashes red or green, this signifies that the display has developed a problem. When this happens, be sure to remove the power plug from the receptacle to prevent fire or electric shock. Then contact your dealer.


• Install the display in a location close to a main power supply outlet, and where the emergency stop button can be easily reached.

- Cables for connecting the display to external equipment are not supplied. Contact your dealer for more information on these products.
- · In order to facilitate the explanations, pictures and diagrams in this manual may differ slightly from the actual items.

## **USING THE REMOTE CONTROL**

### REMOTE CONTROL (for the W/R models)

For details, see page  $\rightarrow$ .



① 👛 button → E-12

Switches between Power On and Standby.

② MUTE button) → E-13

Temporarily mutes the audio.

To return the audio to normal, press this button once again, or press the does the work also.

3 DISPLAY button) → E-16

Press this button to display the input mode, and screen size status.

The status is displayed for about five seconds.

④ CPICTURE MODE button) → E-16

Use this button to switch the Picture Mode.

⑤ (PICTURE MEMORY button) → E-16

Press this button to recall a Picture Memory.

Switches the screen size.

⑦  $\bigcap^{\text{RGB1}}$  -  $\bigcap^{\text{RGB2}}$  (RGB input mode selector button) → E-15

Selects RGB1 - 2.

(RGB3/VIDEO4 imput mode selector button) → E-14

Selects VIDEO4.

Selects VIDEO1 - 3.

(Volume adjustment buttons) → E-13

Press these buttons to adjust the volume.

① (MENU button) → E-19–E-35

Press this button to display the menu screen for adjusting the picture and/or the audio.

(ENTER button) → E-19–E-35

Press this button to fix the entry in the ADJUSTMENT MENU.

3 - - - (Adjustment buttons) → E-19–E-35

Use these buttons to select the item or adjust the value in the menu screen.


#### Note

• Functions may not be available with some models and some device options.

# **USING THE REMOTE CONTROL (Continued)**

## **REMOTE CONTROL** (for the U model)

For details, see page →.



① 👛 button → E-12

Switches between Power On and Standby.

② MUTE button) → E-13

Temporarily mutes the audio.

To return the audio to normal, press this button once again, or press the occurrence work also.

3 DISPLAY button) → E-16

Press this button to display the input mode, and screen size status.

The status is displayed for about five seconds.

(PICTURE MODE button) → E-16

Use this button to switch the Picture Mode.

(PICTURE MEMORY button) → E-16

Press this button to recall a Picture Memory.

Switches the screen size.

Selects VIDEO1 - 5.

(8)  $\bigcirc$  RGB1 −  $\bigcirc$  RGB input mode selector button) → E-15

Selects RGB1 - 2.

Press these buttons to adjust the volume.

 $\bigcirc$  MENU button) → E-19–E-35

Press this button to display the menu screen for adjusting the picture and/or the audio.

(ENTER button) → E-19–E-35

Press this button to fix the entry in the ADJUSTMENT MENU.

(a) (b) (Adjustment buttons) → E-19–E-35

Use these buttons to select the item or adjust the value in the menu screen.

#### Note

• Functions may not be available with some models and some device options.

### **PUTTING BATTERIES IN THE REMOTE CONTROL**



(1) To remove the cover, slide it outwards while pressing it down.



(2) Place two AA batteries in the remote control. Make sure that the batteries are properly oriented.



(3) Close the cover until it snaps into place.

### **PRECAUTIONS**

To prevent malfunction, be sure not to apply any form of severe shock to the remote control.

To prevent malfunction or deformation, be sure not to allow the remote control to become wet; also, keep it away from hot locations or heating equipment.

Be sure not to clean the remote control using a cloth dampened in any volatile solvent, such as benzene or thinner.

#### **CAUTION**

Be sure to use replacement batteries of the same type as the original ones.

When disposing of used batteries, please comply with governmental regulations or environmental public institution's rules that apply in your country/ area.

### Note


The remote control will not function properly if the batteries are dead. Be sure to replace them as needed. Do not use rechargeable batteries (Ni-Cd, etc.).

# **USING THE REMOTE CONTROL (Continued)**

### **EFFECTIVE RANGE FOR THE REMOTE CONTROL**

Point the remote control at the display's signal receiver when using it.

Make sure that there are no obstacles between the remote control and the display's signal receiver.




#### Note

The remote control may not function properly if you use a high-frequency fluorescent lamp. If you experience problems, move the lamp or use the remote control from a different position.

## **CONNECTING THE DISPLAY TO EXTERNAL EQUIPMENT**


## **EXAMPLE OF CONNECTION TO EXTERNAL COMPONENTS**



# **CONNECTING THE DISPLAY TO EXTERNAL EQUIPMENT (Continued)**

## **VCR**


- Connect the video signal cable to either the S-video input terminal or the video input terminal.
- If the unit to be connected is equipped with S-video output terminal, it is recommended to connect to the S-video terminal.



**Display bottom** 

### **DVD RECORDER/PLAYER**

- Connect the video signal cable to the HDMI input terminal, component video input terminal, S-video input terminal, or the video input terminal.
- If the component to be connected is equipped with HDMI output terminal, component video output terminal, it is recommended to connect to the component video terminal.




- Unplug the power cord from the AC outlet before you connect external components.
- Also refer to the instructions for the component to be connected.
- When inputting audio, connect to the terminals corresponding to the used video input or RGB input.
- Terminal layout may differ and functions may not be available with some models and some device options.

# **CONNECTING THE DISPLAY TO EXTERNAL EQUIPMENT (Continued)**


## SATELLITE TUNER

- Connect the video signal cable to the HDMI input terminal, component video input terminal, S-video input terminal, or the video input terminal.
- If the component to be connected is equipped with HDMI output terminal, component video output terminal, it is recommended to connect to the component video terminal.



### PC

• As the cable for connecting a PC differs with the PC model, please consult your dealer for information on the right cable to purchase.



Diopidy Doctor

- Unplug the power cord from the AC outlet before you connect external components.
- Also refer to the instructions for the component to be connected.
- When inputting audio, connect to the terminals corresponding to the used video input or RGB input.
- Terminal layout may differ and functions may not be available with some models and some device options.

## **BASIC OPERATIONS**

### **TURNING THE POWER ON AND STAND-BY**



\* You can also use the buttons on the display's control panel to perform these steps. (for the W/R models)



\* You can also use the buttons on the display's control panel to perform these steps. (for the U model) Press  $\bigcirc$ /I to the left at the bottom of the display to the ON  $\bigcirc$  state.

The power lamp lights up.

- Press on the remote control.

  The color of the power lamp changes from "Red" to "Green".
- **9** Press  $\bigcirc$  or  $\bigcirc$  or  $\bigcirc$  RGB1  $\bigcirc$  Select the video mode to input.
- Press when the power is ON.
  The color of the power lamp changes from "Green"
  to "Red" and the the power turns "OFF (Stand-by

## ADJUSTING THE VOLUME



### Adjusting the volume

Press  $\stackrel{\text{VOL}}{+}$  to increase the volume.

Press on to reduce the volume.

\* Note that the volume level remains stored even when you turn OFF the power.

### Muting the audio

Press MUTE.

The audio is removed.

Press again to restore the audio to the original level.

The mute mode can also be released by pressing the volume buttons.



When the volume adjustment button is pressed

\* You can also use the buttons on the display's control panel to perform these steps.

(Ex. the W model)

### Note

• Functions may not be available with some models and some device options.

## **SELECTING INPUT MODE**

### **VIDEO INPUT MODE (for the W/R models)**



\* You can also use the buttons on the display's control panel to perform these steps. 1

### Press to select the input mode.

You can select from VIDEO1 mode to VIDEO4 mode.

The video modes corresponding to each input terminal are as follows.

- VIDEO1: Video
- VIDEO2: S-video
- VIDEO3: Component video
- VIDEO4: Component video
- \* For selection of the input terminal, see "SETTING THE INPUT TERMINALS" on P. E-31.



Video1 mode

## panel to perform these steps.

## **VIDEO INPUT MODE (for the U model)**



\* You can also use the buttons on the display's control panel to perform these steps. 1

### Press to select the input mode.

You can select from VIDEO1 mode to VIDEO5 mode.

The video modes corresponding to each input terminal are as follows.

- VIDEO1: Video
- VIDEO2: S-video
- VIDEO3: Component video
- VIDEO4: Component video
- VIDEO5: HDMI
- \* For selection of the input terminal, see "SETTING THE INPUT TERMINALS" on P. E-31.



Video1 mode

## **RGB INPUT MODE**



\* You can also use the buttons on the display's control panel to perform these steps. (Ex. the U model)


# Press to select the input mode. You can select between the modes from RGB1 to

RGB2.

The input terminal of each RGB mode is as follows. [for the W/U models]

• RGB1: DVI-D • RGB2: mD-sub [for the R model]

• RGB1: mD-sub





RGB1 mode

## **OTHER BASIC OPERATIONS**

### **CONVENIENT FUNCTIONS**



(Ex. the W/R models)

### **On-screen information**

Press DISPLAY.

The mode is indicated on the screen for 5 seconds.

#### **Picture Mode**

Press MODE .

This button can be used to switch the picture mode.

In the picture mode, you can switch between the set status and the fine mode.

\* For the picture mode settings, see "Setting Picture Mode (P. E-22)".

### **Picture Memory**

Press PICTURE MEMORY

This button can be used to recall the settings of the picture memories 1 - 8. Each time this button is pressed, the setting changes as follows.

 $\hspace{-1cm} \longrightarrow \hspace{-1cm} \text{Memory1} \longrightarrow \hspace{-1cm} \text{Memory2} \longrightarrow \hspace{-1cm} \text{Memory3} \longrightarrow \hspace{-1cm} \text{Memory5} \longrightarrow \hspace{-1cm} \text{Memory6} \longrightarrow \hspace{-1cm} \text{Memory7} \longrightarrow \hspace{-1cm} \text{Memory8} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \longrightarrow \hspace{-1cm} \text{Memory9} \longrightarrow \hspace{-1cm} \longrightarrow \hspace{-1c$ 

\* For the picture memory settings, see "Setting Picture Memory (P. E-22)".

#### Note

• Functions may not be available with some models and some device options.

## WATCHING PICTURES ON THE WIDE SCREEN

### **SWITCHING BETWEEN SCREEN SIZES**



\* You can also use the buttons on the display's control panel to perform these steps. (Ex. the W/R models) Press DE.

The currently selected mode will appear.

Press to select a desired Screen Size.

Each time you press , a different Screen Size appears. The sequences used are as follows:


When you are in a Video input mode

Normal→Wide1→Wide2 Zoom2 ← Zoom1 ←

When you are in an RGB input mode

Normal → Wide → Zoom -

\* Depending on the type of signal, some aspects may not be selected.



Normal mode



Wide1 mode

- Displaying a picture in a Normal mode for extended periods of time may cause phosphor burn-in.
- A variety of Screen Sizes are available with this display. Remember that if you select a mode with an aspect ratio (ratio of frame width to frame height) different from that of the TV program or video media, the pictures will appear differently than if you had selected a mode having the same aspect ratio.
- Showing a movie or similar premium event at a different aspect ratio from its original one at any event site, restaurant, or bar for profit-making purposes or for a public audience may constitute a copyright infringement.
   For films, try to select a mode having the same aspect ratio as the original picture; this enables the director's original intentions to be preserved.
- See P. E-27 for how to adjust the picture size and position.

## **WATCHING PICTURES ON THE WIDE SCREEN (Continued)**

### **SCREEN SIZE**

### Normal (Video/RGB)

Displays pictures of normal size (i.e., a 4:3 aspect ratio).

### Wide1 (Video)

Displays natural-looking pictures of standard size on the wide screen.

### Wide2 (Video)/Wide (RGB)

Ideal for displaying vertically extended pictures such as squeezed pictures.


### Zoom1 (Video)/Zoom (RGB)

Enlarges horizontally extended pictures equally in all directions to maintain the aspect ratio constant.

### Zoom2 (Video)


Reduces the height of horizontally extended pictures with captions, without eliminating the caption. Only the height of pictures is reduced, not the height of the caption.

(Captions may not be easy to read, however, depending on the picture.)



### **ASPECT RATIO**

The following aspect ratios are available.




#### Note

You may find dark areas on top and at the bottom of the screen if you select one of the Zoom modes for media while using the Vision or Cinema Vision size i.e., the sizes used frequently for picture software.

• Functions may not be available with some models and some device options.

## **ADJUSTMENT MENU**

The numbers in parentheses ( ) indicate the reference page numbers.



- The shaded menu items are applied to the U model only.
- · Some type of signal can not be selected.

## **BASIC PROCEDURE OF ADJUSTMENT MENU OPERATIONS**

• Below is shown the basic procedure to make changes to the options in the ADJUSTMENT MENU. (Ex.: adjusting tint setting (Tint))



(Ex. the W/R models)

Press O.
The main menu screen will appear.

Press ( or ( ) to select "PICTURE". Each time you press ( ) or ( ), one of the available

menus appears in the following sequence:

PICTURE ↔ POSITION/SIZE ↔ AUDIO ↔ FEATURES ↔ **FACTORY DEFAULT** 

The PICTURE Menu screen will appear.


Press o or to select "Tint".

Press .

The "Tint" adjustment screen will appear.




"PICTURE" selected in the main menu screen



"Tint" selected in the PICTURE Menu screen

- Press (•) or (•) to change tint values.
  - ( ): More greenish colors
  - (i): More purplish colors
- Press oto store.
- Press  $\overset{\text{\tiny{MENU}}}{\bigcirc}$  when you finish.
  - \* Repeat steps 3, 4, 5 and 6 when you wish to make changes to other options.
  - \* When  $\stackrel{\mbox{\tiny ENTER}}{\bigcirc}$  is pressed after you have selected "Default", the settings are returned to those that were valid when you purchased the set.
  - \* Press  $\bigcap^{MENU}$  to halt the operation in progress.



"Tint" adjustment screen

- On-screen information disappears if you do not take any action for about 60 seconds.
- Functions may not be available with some models and some device options.
- The adjustment range varies with the display signal. You can adjust the display quality to the value you want within the adjustable range.

## **ADJUSTING THE PICTURE**

• Picture-related items can be set and adjusted in the Picture Adjustment Screen. See BASIC PROCEDURE OF ADJUSTMENT MENU OPERATIONS on page E-20 for the basic operation procedures.

Adi	iustina	the	Signal	Contrast
		••••		

Press ( ) to increase the input signal contrast.

Press ( ) to reduce the input signal contrast.

Press of to store.

### **Adjusting the Drive Contrast**

Press (•) to raise the display's luminance level, and increase the contrast.

Press () to lower the display's luminance level, and reduce the contrast.

Press ot store.

### **Adjusting the Brightness**

Press ( ) to increase the brightness.

Press ( ) to reduce the brightness.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### **Adjusting Color**

Press ( ) to darken the color.

Press () to lighten the color.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### **Adjusting the Tint**

Press ( ) to change the tint to a more greenish color.

Press () to change the tint to a more purplish color.

Press ot store.

### **Adjusting the Sharpness**

Press (•) to sharpen the Sharpness.

Press ( ) to soften the Sharpness.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### **Adjusting the Ambient Sensor**

Automatically adjusts the Sharpness to an optimized level that matches the brightness of the surrounding area.

Each time () or () is pressed, the setting is switched.

On ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.

## **ADJUSTING THE PICTURE (Continued)**

### **Setting Picture Mode**

Each time you press ( ) or ( ) , the available choices appear in the following sequence.

➤ Natural ≺→ Fine ≺→ Effective ≺→ Conventional ≺→ Still ←

**[Natural]**: Enables you to watch pictures with natural color tones and high picture clarity. This mode is suitable for watching a normal motion picture.

[Fine]: Suitable for watching a dark picture such as a movie.

**[Effective]**: Displays a screen with detailed contrast.

[Conventional]: Displays a screen approximating that of a conventional TV screen.

**[Still]**: Suitable for viewing a still picture.

adjustment values stored in the selected Memory.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### Precision Setting (for the U model)

Enables advanced Sharpness adjustments.

See page E-23 for details.

### **Setting Picture Memory**


The adjustment status of eight groups of picture adjustment settings can be stored, enabling you to quickly switch to your desired group of settings for the picture you are planning to watch.



Picture Memory Selection Screen

Save
Memory 1
Memory 2
Memory 3
Memory 4
Memory 5
Memory 6
Memory 6
Memory 7
Memory 8

"Save" Selection Screen



"Load" Selection Screen

**[Save]**: Use  $\bigcirc$  or  $\bigcirc$  to select Memory 1 - 8. If  $\bigcirc$  is pressed, the current picture adjustment values are stored to the selected Memory.

[Load]: Use  $\bigcirc$  or  $\bigcirc$  to select Memory 1 - 8. When  $\stackrel{\square}{\bigcirc}$  is pressed, the values becomes the picture

# **PRECISION SETTING (for the U model)**

• See BASIC PROCEDURE OF ADJUSTMENT MENU OPERATIONS on page E-20.

Even more advanced Sharpness adjustments can be made as required.

## **Adjusting the Black Level**

Press (•) to strengthen the reproduction of black. (Provides a picture quality with deep blacks.)

Press ( ) to weaken the reproduction of black.

Press of to store.

## **Setting Detail Gradation**

Corrects the gradation of the light and dark areas of the picture.

Each time () or () is pressed, the setting is switched.

On ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.



Precision Setting Selection Screen

## **Setting 3D NR**

This enables noise reduction processing with respect to the input signal noise level (reduces screen flicker for more comfortable viewing).

Each time you press (•) or (•), the available choices appear in the following sequence.

Press of to store.

### **Setting CODEC NR**

This enables noise reduction processing of mosquito noise or block noise generated when digital picture signals are recorded or replayed.

Each time you press () or (), the available choices appear in the following sequence.



Press of to store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.

# **ADJUSTING THE PICTURE (Continued)**

### **Setting Image Enhance**

This performs detailed image quality settings.

#### Chroma Transient

This function corrects the color contours.

Each time (•) or (•) is pressed, the setting is switched.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### · Image Identify

This function discerns between the natural image display section and the text display section, and performs correction to enable an optimized display for each.

Each time () or () is pressed, the setting is switched.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### Adjusting the Color Temp.

Use ① or ② to specify a desired color temperature. Each time you press ② or ⑤, one of the available choices appears in the following sequence:

[-3500]: More reddish colors

[+3500]: More bluish colors

[User]: User Color Temp. setup

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

## **Setting User Color Temp.**

Use  $\bigcirc$  or  $\bigcirc$  to select Red, Green, or Blue, and adjust the color temp. for each.

Press (): to strengthen the selected color.

Press (•): to weaken the selected color.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### **Setting the Color Focus**

This enables correction with respect to specific color hues within the image.

Independent correction of the hue of skin colors, blue skies, and so on, enables a more brilliant display.

### · [Reddish color]

With red at the center, performs the following corrections with respect to the range from magenta to vellow.

[Tint]: Use ( ) and ( ) to adjust the hue.

**[Color]**: Use (a) and (b) to adjust the color depth.

**[Red]**: Use (a) and (b) to adjust the strength of the red color range.

**[Green]**: Use () and () to adjust the strength of the green color range.

[Blue]: Use () and () to adjust the strength of the blue color range.

Press  $\bigcap^{\text{ENTER}}$  to store.

Adjustments can be made in the same way for:

- [Greenish color]: (With green at the center, performs corrections with respect to the range from yellow to cyan.)
- [Bluish color]: (With blue at the center, performs corrections with respect to the range from cyan to magenta.)

### • [Targeting Red]

This function corrects the hue and color depth with respect to Red.

[Tint]: Use () and () to adjust the hue.

**[Color]**: Use (a) and (b) to adjust the color depth.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

Adjustments can be made in the same way for:

- [Targeting Yellow] (Performs correction with respect to Yellow.)
- [Targeting Green] (Performs correction with respect to Green.)
- [Targeting Cyan] (Performs correction with respect to Cyan.)
- [Targeting Blue] (Performs correction with respect to Blue.)
- [Targeting Magenta] (Performs correction with respect to Magenta.)

### • [Targeting White]

Corrects red, green, and blue with respect to white.


[Red]: Use () and () to adjust Red.

**[Green]**: Use () and () to adjust Green.

[Blue]: Use () and () to adjust Blue.

Press ot store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.



Color Focus (Reddish color) Settings Screen

# **ADJUSTING THE PICTURE (Continued)**

### **Making the Progressive Scan Settings**

This sets the conversion processing of interlace signals to block receive signals.

#### • 24 Frame Mode

This function enables the optimized display of movies, etc. with 24 frames/second signals.

Each time (•) or (•) is pressed, the setting is switched.

Auto ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.



#### Progressive Scan Settings Screen

### • 30 Frame Mode

This function enables the optimized display of movies, etc. with 30 frames/second signals.

Each time () or () is pressed, the setting is switched.

Auto ↔ Off

Press of to store.

### Jaggies Filter

This function alleviates the phenomenon where jagged diagonal lines can be seen when interlace signals are input, thus enabling a smoother motion picture display.

Each time ( ) or ( ) is pressed, the setting is switched.

Auto ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### Motion Setting

The detecting sensitivity for motion picture is set.

The response of the picture processing is valued in the motion picture priority setting.

Press (): to specify still picture priority.

Press (): to specify motion picture priority.

Press of to store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.

# **ADJUSTING SCREEN POSITION AND SIZE**

- You can make changes to all screen adjustment options in the POSITION/SIZE Menu. See Page E-20 for the basic operation procedures.
- The changes you make will be stored for the selected input mode. Therefore, you need to select a desired input mode before making any changes.



POSITION/SIZE Menu screen

# **Adjusting Screen Position (Position)**

Horizontal position (Horizontal)

(i): Moves screen to the right.



(i): Moves screen to the left.



Vertical position (Vertical)

: Moves screen up.



: Moves screen down.



Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

# **Adjusting Screen Size (Size)**

Screen width (Width)

( ): Increases width.



(): Reduces width.



Screen height (Height)

: Increases height.




: Reduces height.



Press of to store.



"Position" adjustment screen



"Size" adjustment screen

<sup>\*</sup>You cannot adjust screen size in DVI-D mode.

# **ADJUSTING AUDIO**

- You can make changes to all audio adjustment options in the AUDIO Menu. See Page E-20 for the basic operation procedures.
- The changes you make will be stored for the selected input mode. Therefore, you need to select a desired input mode before making any changes.

# **Adjusting Treble (Treble)**

Press (•) (•) to make adjustments.

( ): Stronger treble

(): Weaker treble

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

# **Adjusting Bass (Bass)**

Press (•) (•) to make adjustments.

( ): Stronger bass

(): Weaker bass

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

# **Adjusting Volume Balance (Balance)**

Press (•) (•) to make adjustments.

(•): Shifts the volume balance towards the right.

(): Shifts the volume balance towards the left.

Press  $\stackrel{\text{\tiny ENTER}}{\bigcirc}$  to store.

# **Setting Loudness (Loudness)**

Corrects the balance between bass and treble for easy listening even with weak volume.

Each time you press () or (), one of the available choices appears in the following sequence:

On ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- · Depending on the type of signal, it may not be possible to make some of the settings or adjustments.
- Audio Input menu will not be displayed when "No Audio" is selected. (See P. E-36.)



# **OTHER ADJUSTMENTS**

• FEATURES setup screen has the following 4 options.

See Page E-20 for the basic operation procedures.

[Adjustment]: Can make a fine adjustment of pictures such as Dot Clock, Clamp Position.

[On Screen Menu]: Can make a display setting such as OSD, Language. (See P. E-30.)

[Input Terminal]: Can make an input terminal setting such as Video Input. (See P. E-31.)

[Others]: Used to make Screen Orbiter and other settings. (See P. E-32–E-34.)

# **ADJUSTMENT**

Dot Clock, Clock Phase, Clamp Position, and Auto Calibration are adjusted as shown in the following chart.

Select the item with  $\bigcirc$   $\bigcirc$  , and then adjust with  $\bigcirc$   $\bigcirc$ . Finally, press  $\stackrel{\text{\tiny EMTR}}{\bigcirc}$  to implement the adjustments.

Adjustment Item	Contents of Adjustments	Operation
Dot Clock (mD-sub)	You may find the vertically-striped pattern in pictures, depending on the clock frequency of your PC's processor. If you experience blurring, you can obtain a clearer picture by adjusting the "Dot Clock".	Use (2) (5) to adjust to minimize vertically- striped pattern in pictures.
Clock Phase (mD-sub)	Pictures and the outline of letters may blur or flicker as the clock phase of your PC may be different. In this case, adjust the clock phase manually. Normally, the automatic setting ensures the optimal value.	Use ( ) to adjust to minimize pictures blur.
Clamp Position (mD-sub, Comp. video)	Adjusts the extremely dark or bright pictures. Normally, the automatic setting ensures the optimal value.	Use () () to adjust pictures optimally.
Auto Calibration (mD-sub)	Adjusts the dynamic range of images to the optimum. Performed while a white screen signal is received.	Display the Auto Calibration screen and select Execute, and then use  to select the item.

# **OTHER ADJUSTMENTS (Continued)**

# **ON SCREEN MENU**

### Setting Display Information (OSD)

You can use this option to select whether to display information other than menus. (Error messages are displayed regardless of what choice you make for this option.)

Each time you press () or (), one of the available choices appears in the following sequence:

→ On(OSD:bright) ↔ On(OSD:dark) ↔ Off ←

[On (OSD:bright)]: On-screen information shown in light color.

[On (OSD:dark)]: On-screen information shown in dark color.

[Off]: Except for menus and error messages, on-screen information is not displayed.

Press ot store.

\* When the screen is white [On (OSD:dark)], some of the information may be difficult to read.

## • Selecting Language (Language)

You can use this option to select the language displayed on the screen.

(1) Select "Language" and press

The "Language" selection screen will appear.

(2) Press or to select your desired language.

English

Español (Spanish)

Français (French)

Português (Portuguese)

Русский (Russian) for the R model

(3) Press Press

The menu is displayed in the selected language.

### • Selection of indications (Name Select)

You can change the settings for indications for video inputs and RGB inputs.

#### Video input

You can change the settings for indications for the VIDEO inputs.

Select the desired indication in accordance with the connected equipment.

Each time (•) (•) is pressed, the setting is switched. (In the case of VIDEO1)

Press of to store.

## **RGB** input

You can change the settings for indications for the RGB inputs.

Select the desired indication in accordance with the connected equipment.


Each time  $\bigcirc$   $\bigcirc$  is pressed, the setting is switched. (In the case of RGB 1)

→ RGB1 ←→ PC1 ←→ PC2 ←→ DVD1 ←→ DVD2 ←→ STB ←→ Satellite ←→ Cable TV ←

Press on to store.



OSD selection screen



"Language" selection screen (In the case of the W/U model)

# **SETTING THE INPUT TERMINALS**

### • Selecting the settings of Video/S-video Input terminal

You can use this option to select the color format appropriate for the input signal.

Each time you press () or (), one of the available modes appears in the following sequence:

 $\rightarrow$ Auto1 $\leftrightarrow$ Auto2 $\leftrightarrow$ NTSC $\leftrightarrow$ PAL $\leftrightarrow$ SECAM $\leftrightarrow$ PAL60 $\leftrightarrow$ N-PAL $\leftrightarrow$ M-PAL $\leftrightarrow$ 4.43NTSC $\leftarrow$ 

[Auto1]: Automatically selects NTSC, PAL and SECAM.

[Auto2]: Automatically selects NTSC and M-PAL.

[Other than Auto]: You need to select a system appropriate to the input signal.

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

### · Selecting the settings of D-SUB Input terminal

You can use this option to select the signal system it will receive to D-SUB Input terminal.

(1) Select D-SUB Input and press  $\stackrel{\text{ENTER}}{\bigcirc}$ .

D-SUB Input screen appears.

(2) Select the signal system to receive.

Each time you press ( ) or ( ), one of the available choices appears in the following sequence:

RGB-PC ↔ Decoder

[RGB-PC]: For using RGB for PC

[Decoder]: For using digital broadcast tuner

(3) Press on to store.



Input Terminal Settings Screen

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.

# **OTHER ADJUSTMENTS (Continued)**

# **OTHER SETTINGS**

#### Auto Off-NO SIG.

You can make to the standby state automatically when the no signal state continued during set up time.

Press to select the "Time".

Press  $\bigcirc$   $\bigcirc$  to select the amount of time before the standby state starts.

↑ Off ← 1 min. ← 15 min. ← 45 min. ← 60 min. ←

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

\* The numerical value is the approximate amount of time before the standby state starts.

You can assign the black or white color for the background color at the no signal state.

Press to select the "Background".

Press () () to select the displayed background displayed.

Black ↔ White

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

\* The background color changes to assigned color state after approximate 20 seconds at the no signal state.

### Selecting input terminals (Audio Input)

You can use this option to select the available terminals to receive the audio from input equipment.

(1) Select "Audio Input" and press .

The "Audio Input" selection screen will appear.

- (2) Press or to select video input terminal.
- (3) Select a related audio input terminal.

Each time you press (•) or (•), one of the available choices appears in the following sequence:

→No Audio ←→Audio 1←→Audio 2←→Audio 3←→Audio 4←

[No audio]: No audio in the corresponding mode.


[Audio 1-3]: Selects Audio 1 through 3 for receiving audio in the corresponding mode.

[Audio 4]: HDMI(for the U model)

- \* Repeat steps (2) and (3) for each piece of input equipment.
- (4) Press on to store.
  - \* Audio Input menu will not be displayed when "No Audio" is selected.



Auto Off-NO SIG. settings screen



"Audio Input" selection screen (In the case of the U model)

## • Minimizing phosphor burn-in (Screen Orbiter)

for RGB

You can use this option to move the screen position to minimize phosphor-induced "burn-in". Follow the steps below.

(1) Select "Screen Orbiter" and press on the series of the

The "Screen Orbiter" setting screen will appear.

- (2) Press o or to select "Mode/Time".
- (3) Select a desired pattern.

Each time you press  $\bigcirc$  or  $\bigcirc$ , one of the available choices appears in the following sequence:



[Off]: Disables Screen Orbiter.

[Time]: Moves the pattern approximately every one hour.

[Mode]: Moves the pattern when the power is turned ON or when you switch between modes.

- (4) Press or to select "Moving Area".
- (5) Press ( ) or ( ) to select the range for moving the pattern.

Each time you press ( ) or ( ), one of the available choices appears in the following sequence:

[Min.]: Pattern moves in small range. (About 5 pixels)

[Std.]: Pattern moves in moderate range. (About 10 pixels)

[Max.]: Pattern moves in wide range. (About 15 pixels)

- (6) Press on to store.
  - \* When the Screen Orbiter function is operated, some letters at the top, bottom, right or left of the screen may be missed.

### • Setting RGB Input Signal Compulsorily (Direct Setting)

for RGB

You can use this option to switch the setting for RGB input signal.

Each time you press ( ) or ( ), one of the available choices appears in the following sequence:

$$\rightarrow$$
Auto $\rightarrow$ VGA $\rightarrow$ WVGA $\rightarrow$ 480P $\rightarrow$ XGA $\rightarrow$ WXGA $\rightarrow$ SXGA $\rightarrow$ SXGA $\rightarrow$ 

[Auto]: The optimum display is obtained automatically for input signals.

[Others]: The optimum resolution setting is fixed for each signal.

Press of to store.

- \* In Auto mode, the resolution of VGA, WVGA, 480P, XGA, WXGA, SXGA and SXGA<sup>+</sup> may not be automatically distinguished. Switch to the fixed display when the image is not displayed properly.
- \* Signals that are not applicable depending on the model or input terminals may not be displayed.

### • Specifying RGB Input Signal (Code Setting)

for mD-sub input

Normally, use this option in Auto mode.

· Displaying white over entire screen (White Screen)

You can use this option to display white over the entire screen to minimize phosphor burn-in.

Each time you press  $\bigcirc$  or  $\bigcirc$ , one of the available choices appears in the following sequence:

On ↔ Off

Press  $\stackrel{\text{ENTER}}{\bigcirc}$  to store.

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.



"Screen Orbiter" setting screen

# **OTHER ADJUSTMENTS (Continued)**

## • Setting Exhibition Mode (Exhibition Mode)

You can use this option to display the enhanced contrast, which is most suitable for the use by unspecified persons.

Each time you press ( ) or ( ), one of the available choices appears in the following sequence:

On ↔ Off

Press ot store.

- \* In Exhibition mode, the display returns to the original setting in about 5 minutes even if the adjustment is changed.
- \* The setup will be cancelled when removing the power plug from the receptacle.

### • Displaying System Status (Information)

Displays system operation status.

Select "Information" and press .

The "Information" screen will appear.


[Mode]: Input mode appears at the upper right corner of the screen

[Freq. Scan Mode]: Frequency scanning

[Input Signal]: Video mode [Input Sync.]: Signal type

[Freq.]: Synchronized signal frequency, polarity

[Preset No.]: RGB code number



Information screen (Video Mode)



Information screen (RGB Mode)

- The screen display disappears if there is no operation within approximately 60 seconds.
- Depending on the model or the optional devices, some of the functions may not be available.
- The adjustment range varies according to the display signals. Make adjustments to your preferred Sharpness within the adjustment range.
- Depending on the type of signal, it may not be possible to make some of the settings or adjustments.

# INITIALIZATION OF USER ADJUSTMENT VALUE

You can restore the values of the adjustment/setting made in the MENU to factory settings.



(Ex. the W/R models)

Press O.

The main menu screen will appear.

Press () or () to select "FACTORY DEFAULT".

Each time you press  $\bigcirc$  or  $\bigcirc$ , one of the available menus appears in the following sequence:

PICTURE ↔ POSITION/SIZE ↔ AUDIO ↔ FEATURES ↔ FACTORY DEFAULT

The FACTORY DEFAULT Menu screen will appear.

**↑** Press □.

 Displays the message of whether to proceed with the initialization.





 The message of having completed the initialization will be displayed after initializing.

6 Press <sup>MENU</sup> when you finish.



"FACTORY DEFAULT" selected in the main menu screen



Displays the message of whether to proceed the initialization



Displays the message of having completed the initialization

# **CLEANING AND MAINTENANCE**

### **Precautions**

Be sure to remove the power plug from the receptacle before cleaning the display.

Be sure not to clean the display using a cloth dampened with volatile solvents, such as benzene or thinner. Such solvents can harm the display's cabinet, the filter at the screen front, and the remote control. They can also cause paint to come off these sections.

### **Cleaning the Screen**

Clean the screen gently with a soft cloth.

The screen surface is fragile. Never attempt to clean it with a hard material, press on it forcefully, or tap it.

#### **Cleaning the Cabinet and Remote Control**

Use a soft cloth for cleaning.

If the cabinet or remote control is heavily stained, soak a soft cloth in a mixture of water and detergent and squeeze it dry before wiping off the stains. Use a soft, dry cloth for final cleaning.

### Cleaning the ventilation grille

Remove dust from the ventilation grille in the rear of the main unit periodically with a vacuum cleaner as the accumulated dust can increase the internal temperature of the main unit causing machine failure or fire hazard.

# **BEFORE OBTAINING SERVICE**

In the event of problems with the display, check the following explanations before contacting your dealer for servicing.

Problem	Action
Power does not turn ON.	Check whether the power plug is securely inserted into the receptacle.
No pictures are displayed.	<ul> <li>Check cables for disconnection.</li> <li>Check whether the power for all input equipment is ON.</li> <li>Check for connection to wrong terminals or for wrong input mode.</li> <li>Check whether the input mode display is colored pink. Special setup may have been made. Return to original setup or initialize the User adjustment value.</li> </ul>
Remote control does not function properly.	<ul> <li>Check for incorrect battery orientation.</li> <li>Check for dead batteries.</li> <li>Check for distance from the display.</li> <li>Check whether you are pointing the remote control transmitter properly at the display's receiver.</li> <li>Check for any obstacle between the remote control and the display.</li> </ul>
The display makes a snapping sound.	• This sound is produced when the cabinet expands or contracts due to variations in temperature. This sound does not indicate that the display has a problem.
The display makes a buzzing sound.	• The display has fans to maintain the temperature of internal components at a constant level. This sound is produced by the fan as it rotates. (Applies to models equipped with a fan)
• There are spots on the screen.	Check whether your AV equipment is affected by interference from automobiles, trains, high-voltage transmission lines, neon signs or other potential sources of interference.
Degraded colors/tints	Check whether all picture adjustments have been properly made.  (See "Adjusting Pictures" on P. E-21–E-26.)
Improper screen position/size	Check whether screen position and size have been properly adjusted.     (See "Adjusting Screen Position and Size" on P. E-27.)
No audio	<ul> <li>Check cables for disconnection.</li> <li>Check whether the proper audio input has been selected. (See "Audio Input" on P. E-32.)</li> </ul>
<ul> <li>If "Out of range" appears, the display is receiving a signal whose picture or signal cannot be reproduced by the display.</li> <li>The screen turns to black and white.</li> </ul>	• Signals that are not supported by this display have been input. Check which signals are supported. (See the user's manual (1/2).)
• If "Error message Condition 1" appears, the fan is defective.	• Remove the power plug from the receptacle, and contact your dealer for repairs.  (Applies to models equipped with a fan)
• If "Error message Condition 2" appears, the display's internal components are extremely hot.	• Remove the power plug from the receptacle. (You can turn the power back ON again when the components have cooled sufficiently.) If the message appears again when you turn the power back on, remove the power plug from the receptacle, and contact your dealer for a repairs.
• If "Change refresh rate to 60Hz" appears,	• The picture may get blurred with vertical frequency of other than 48.3-51.8 or 58.4-61.4 (Hz). Change the setting of your PC, etc.
• If the power indicator lamp flashes red or green.	Remove the power plug from the receptacle, and inform your dealer about how the lamp flashed.  The power indicator lamp flashes differently depending on the type of problem.

#### Note

• Functions may not be available with some models and some device options.